Albert-Ludwigs-Universität Freiburg Lecture: Introduction to Mobile Robotics Summer term 2016 Institut für Informatik

Prof. Dr. Wolfram Burgard Dr. Michael Ruhnke Dr. Bastian Steder

mobilerobotics@informatik.uni-freiburg.de

# Sheet 8

Topic: Extended Kalman Filter Due date: 17.06.2016

# General Notice

In this exercise, you will implement an extended Kalman filter (EKF). A framework containing stubs of all the parts of the EKF is provided to you, so you can concentrate on the implementation of the filter itself. The framework for the implementation can be obtained from the website of the course. The tarball contains the following folders:

**data** This folder contains files representing the world definition and sensor readings used by the filter.

octave This folder contains the EKF framework with stubs for you to complete.

plots The framework uses this folder to store images generated by the visualization.

To run the EKF, change into the directory **octave** and launch the *Octave* program. Inside *Octave*, type **extended\_kalman\_filter** to start the EKF. Running the EKF may take some time. While the EKF is running, plots visualizing the state of the filter are generated and stored in the **plots** directory.

Note: You first have to complete all the stubs in order to get the filter working correctly. We use the librobotics library for some of the visualization. All functions defined in the library are available in the framework.

Some implementation tips:

- Turn off the visualization to speed up the computation by commenting out the line plot\_state(... in the file extended\_kalman\_filter.m.
- While debugging run the filter only for a few steps by replacing the for-loop in extended\_kalman\_filter.m by something along the lines of for t = 1:50.
- The command **repmat** allows you to replicate a given matrix in many different ways and is magnitudes faster than using for-loops.
- When converting implementations containing for-loops into a vectorized form it often helps to draw the dimensions of the data involved on a sheet of paper.
- Many of the functions in *Octave* can handle matrices and compute values along the rows or columns of a matrix. Some useful functions that support this are sum, sqrt, and many others.

#### **Exercise 1: Theoretical Considerations**

The EKF is an implementation of the Bayes Filter.

- (a) The Bayes filter processes three probability density functions, i. e.,  $p(x_t \mid u_t, x_{t-1}), p(z_t \mid x_t)$ , and  $bel(x_t)$ . State the normal distributions of the EKF which correspond to these probabilities.
- (b) Explain in a few sentences all of the components of the EKF, i. e.,  $\mu_t$ ,  $\Sigma_t$ , g,  $G_t$ , h,  $H_t$ ,  $Q_t$ ,  $R_t$ ,  $K_t$  and why they are needed. What are the differences and similarities between the KF and the EKF?

## **Exercise 2: EKF Prediction Step**

We assume a differential drive robot operating on a 2-dimensional plane, i.e., its state is defined by  $\langle x, y, \theta \rangle$ . Its motion model is defined on slide 10 (Odometry Model) in the chapter Probabilistic Motion Models of the lecture slides.

- (a) Derive the Jacobian matrix  $G_t$  of the noise-free motion function g. Do not use Octave.
- (b) Implement the prediction step of the EKF in the file prediction\_step.m using your Jacobian  $G_t$ . For the noise in the motion model assume

$$Q_t = \left(\begin{array}{rrr} 0.2 & 0 & 0\\ 0 & 0.2 & 0\\ 0 & 0 & 0.02 \end{array}\right).$$

## **Exercise 3: EKF Correction Step**

- (a) Derive the Jacobian matrix  $H_t$  of the noise-free measurement function h of a rangeonly sensor. Do not use Octave.
- (b) Implement the correction step of the EKF in the file correction\_step.m using your Jacobian  $H_t$ . For the noise in the sensor model assume that  $R_t$  is the diagonal square matrix

$$R_t = \begin{pmatrix} 0.5 & 0 & 0 & \dots \\ 0 & 0.5 & 0 & \dots \\ 0 & 0 & 0.5 & \dots \\ \vdots & \vdots & \vdots & \ddots \end{pmatrix} \in \mathbb{R}^{\operatorname{size}(z_t) \times \operatorname{size}(z_t)}.$$

After having successfully implemented the prediction step and the correction step, you can generate an animation from the saved images using *ffmpeg* or *mencoder*. With *ffmpeg* you can use the following command to generate the animation from inside the **plots** folder:

ffmpeg -r 10 -b 500000 -i kf\_%03d.png ekf.mp4